

MPB SERIES CP1200 CALIBRATION CYLINDER

GENERAL

1. Carefully remove all packaging and pipe plugs where fitted.
2. The Calibration Cylinder must be installed in a vertical position.
3. The Calibration Cylinder should be installed using independent isolation valves.
4. Ensure isolation valves, where fitted, are closed.

Refer to MPVA 807 for dimensional information.

See also technical bulletin MPBTB 087.

CLEANING THE CALIBRATION GLASS

1. Remove instrument from installation and carefully remove one of the end connectors which retains the Calibration Cylinder and seals.
2. Ensure Calibration glass contains no fluid.
3. Carefully remove Cylinder from CP1200 chassis.
4. Replace seals as necessary, carefully clean interior of tube with suitable solvent and ensure Cylinder and seals are spotlessly clean.
5. Lightly grease o rings. Reverse procedure to reassemble.

NOTE:

Care should be taken not to excessively tilt the glass Cylinder when dismantling and reinstalling.

MPB Industries Ltd - Designers and Manufacturers of Scientific and Process Control Instrumentation

Part of the Scientific Digital Imaging plc (SDI) group of companies
Unit 1 Branbridges Ind Est, East Peckham, Kent TN12 5HF, UK, Tel: +44 (0)1622 872  SDI GROUP
mail@mpbflowmeters.com, www.mpbflowmeters.com

Due to the constant development and improvement of products, information may be altered or withdrawn without notice.